366B Series Counter

366

Based on a powerful built-in microcomputer, the compact 366B is the most versatile and cost-effective counter ATC has ever built. No industrial counter has ever achieved a higher level of reliability and ruggedness than the 366B. It has no moving parts in its electronic logic circuits, only plug-in circuit boards which are computer-tested for reliability and assembled virtually without hand wiring. Its few mechanical components have been selected for reliable service; long life relays with heavy-duty contacts and rotary set point selector switches with extremely low wear characteristics.

**CONTACT BOUNCE AND NOISE IMMUNITY:** No industrial counter offers greater immunity to noise and contact bounce than the 366B. Most noise encountered in typical industrial environments is blocked by such design features as full-wave bridges and a transformer power supply... so effectively that the 366B does not have to be shielded. Furthermore the 366B's microcomputer employs redundant sampling logic to detect and reject any noise pulse that manages to penetrate its defenses. Through the same powerful technique, the microcomputer also detects and rejects even severe contact bounce. As a result, the 366B maintains absolute count accuracy and is virtually immune to false starts and reset, even in difficult industrial environments.

salse Ranger Computing Counter **COMPUTATION:** Through its internal microcomputer, the 366B keeps track of the set point throughout the count cycle. Whenever there is a change in set point, even during a cycle, it instantly recomputes the remaining count and accurately determines the number of counts before count-out. This unique capability is especially valuable in the count-down modes as it allows you to shorten or lengthen a cycle without loss of accuracy.

PROGRAMMABLE DISPLAY: The 366B's three-digit cycle progress display will count UP to or DOWN from the set point, depending on the position of an internal jumper. After count-out, the display will either STOP or GO. In the UP & GO program, the display counts up to the set point and continues to count after count-out; in the DOWN & GO mode, it counts down to the set point, then begins to count up (from zero) after count-out.

WIDE RANGE: Each 366B Long-Ranger covers the overall span of 1 to 99,900 counts in three switch-selected ranges of 1 to 999, 10 to 9990 or 100 to 99,900. It can be optimized within any selected range simply by removing appropriate selector knobs (e.g. with the counter in the 1 to 999 range, you can obtain a tamper-proof span of 1 to 99 by setting the left selector at 0 and removing the knob.) To the right of the three-digit display, a counting bar (\_\_\_) blinks on each time a pulse is received. At left, a marker **v** turns on when the delayed relay is energized at count-out.

SELF-DIAGNOSTICS: A built-in diagnostic program lets you verify--without using any test instrument--that the counter's functional circuits are operating properly. Just follow the instructions on the flip-up card, using the counter's own display for the test readout. If all self-test displays are correct, any malfunction is almost certainly due to external circuits or to the relays, not the counter.

COMPACT, PLUG-IN AND DUST-TIGHT: Packaged in a 72mm<sup>2</sup> DIN housing, the 366B occupies 40% less panel space than most other industrial counters. It is a true plug-in counter that can be replaced in seconds without disturbing housing or wiring. The 366B is also fully gasketed and O ring sealed to be dust and water-tight whether panel or surface-mounted.

POSITIVE RESET TIME AND PULSE LENGTH: Digitally clocked by the microcomputer, the 366B's reset time is consistently of the same duration, regardless of variations in line voltage, power supply or cycle length. When the 366B operates in repeat-cycle mode, the output pulse is also digitally clocked so that both the time of occurrence and its duration are consistent from cycle to cycle.

#### **DIMENSIONS** (INCHES/MILLIMETERS)





WIRING L1 TO POWER SUPPLY (+ ON DC) PULSE INPUT (+ ON DC) (- ON DC) ñ INSTANTANEOUS CONTACTS DELAYED CONTACTS 14 10 1 2 16 15 3 8 6 7 9 4 5 13 11 12 PI PS PULSE INPU POWER SUPPLY **TERMINAL WIRING:** 

INDICATING MODEL

5

### **OPERATION**

As soon as power is applied to terminals 1 & 2 of the counter, the instantaneous relay is energized and changes the states of its associated contacts (8-6-7 & 9-14-10). The counter then looks for terminal 15 (pulse input terminal) to receive input pulses. When the number of pulses received equals the number of counts set on the front face, the delayed relay energize and changes the states of its associated contacts (3-4-5 & 13-11-12).

The counter is reset by removing power from terminal 1 for at least 60 msec. At reset, both relays revert back to their shelf (without power) state. To the right you will find some typical applications.

**SETTING SWITCHES:** The three digits are set with the rotary switch knobs beneath each digit. These knobs can be rotated in either direction (CW or CCW), and they are "pull" removable if digit set security is desired. When the 366B is in the "Count Down" mode, changing one or more digits, during counting, will instantly be reflected by an equivalent change in the counter's display. In the "Count Up" mode, changing digits immediately changes the count-out set point. Setting all three digits to zero will cause instant count-out in any display mode.

THE DISPLAY: A high intensity blue fluorescent display consists of three digits and a Counting Bar with a special Count-Out symbol. The Counting Bar appears to the right of the digits and blinks once every count, regardless of range. When the delay relay is energized at count-out, a triangular Count-Out symbol appears to the left of the digits.

REMOVE THE 366B FROM ITS HOUSING TO MAKE CHANGES SHOWN BELOW.

COUNTING DISPLAY MODES: Down & Stop (30) Up & Stop (30) Down & Go (50) Up & Go (50)

CHANGING THE RANGE: The 366B has three ranges:

- x1 = Counts single pulses to 999
- x10 = Counts every tenth pulse to 9,990
- 12 = Counts every 12th pulse

Predetermining Counters // 366B Series

Each range is selected using finger force on the white plastic lever behind the front face of the counter. In two of the three possible lever positions, an indicator will appear in a range window located on the front face below and between the rotary switch knobs. When nothing appears in these windows, the counter is understood to be in the x 1 range.

MODEL NUMBER >>>>> 366B			Р	Х
Range				
1-999, 10-9990 or 100-99900 (switch selected) 400				
Special 000	1			
Voltage & Frequency				
120, 50/60 Hz	Q			
240, 50/60 Hz	R			
24 VAC, 50 or 60 Hz	Т			
24 VDC				
Specia	K			
Arrangement				
Selectable Count Up or Count Down with Display 30				
Selectable Count Up & Go or Count Down & Go with Display				
Features				
Basic plug-in unit				
Standard unit				
ACCESSORIES – 0353-260-27-00: Surface mounting bracket kit				
0305-265-61-70: Retrofit kit				

## TYPICAL INSTALLATIONS

#### KE

11.0

4

KEY SY	YMBOLS			
PS	POWER SUPPLY		Il tim	ners sho
	INDEPENDENT LOADS	P	off un	less oth
ĕ	DEPENDENT LOADS	Ν	Лахіп	num loa
<u> </u>	MOMENTARY STARTING	l	oad c	arrying
-~~-	SUSTAINED STARTING	P t	'ilot li ermir	ght lea 1al bloc
<u></u>	CONTACT NORMALLY CLOSED	v f	vired uncti	to shov
•	RESET CONTACT	r	ning,	instanta
x	LOAD DE-ENERGIZED LOAD ENERGIZED	0	DN D	ELAY-R
PI	DELAYED CONTACTS	(	PS	INSTA
	Contacts transfer	14 a	- <u>°</u>	Conta
1 - 13 	unit "times out" and	<u>6</u> 0	0-10 0-8	wnen transfe
03	all digits are zero.		7	shown
	SUSTAINED STA	RT		
	SIART SH	Les	)	å.
		-		
	1	<u>и  </u>	_ <b>1</b>	
	1 - 12	Ē	10	
				· · ·
		-	<u></u>	
		DENT L	7 040 L #	4E
			T/C	
			1/3	0317
	STAR' SW	1	)	2
	• 15 (P)	19		Γ
	PULSE SW		].	
	013		0 10	
	t . 5		].	
		<u>.</u>	o	
	[		]7	
			D RI	EPEA
		∲-©	)—	1
		<del>  '</del>		
		1 ; 	~	
	11 012	14		
			10	
	1	<u>si</u>	°*	
	1		÷,	
	• • • • • • • • • • • • • • • • • • •			
	NUEP IN UEP	EN DEN 1	. OAF	i . INF
	NOTE: Minimum sv	ope	n tin	ne: 100
	Minimum se Output Puls	e len:	ath -	ne: 201 - 2001

own in "before start" grams shown with power erwise marked.

ad current through any contact is 5 amperes

ads are brought out to ck. Pilot light can be w practically any desired t energized, cycle runneous or delayed switch

eset on power failure.

- NTANFOUS CONTACTS
- cts are transferred
- power supply is energized; rred back, as
- when de-energized.



AINED START



T CYCLE



mSEC mSEC ox. 50 mSEC



3652602600

650 ohm 20 v

125

# SPECIFICATIONS

	Display model only for operation at 120, 240			Voltage Model		
MODELS	or 24 VAC; and 24 VDC. Unit counts on break (i.e. when count input switch opens). Unit operates in on delay mode only.			120 VAC Model	Turn On 60V 3.5 mA (nom.) Turn Off 30V 2.4 mA (nom.) 10 mA max. current at 120V	
RANGE	Switch-selectable ranges 9990, and 100 to 99900	of 1 to 999, 10 to ).	COUNT INPUT	240 VAC Model	Turn On 120V 3.5 mA (nom.) Turn Off 60V 2.4 mA (nom.) 10 mA max, current at 240V	
REPEAT ACCURACY	100% (+0 count on all ranges)		(terminal 15)	24 VAC	Turn On 12V 9.5mA (nom.) Turn Off $4V_{1}$ 3.8 mA (nom.)	
RESET TIME	Clocked at 40 mSEC	Model		30 mA max. current at 24V		
	AC				Turn On 15 VDC 2.5 mA (nom.)	
	Max. count rate	1000/MIN (symmetrical input)		Model:	Turn Off 3 VDC .5 mA (nom.) 5 mA max. current at 24V	
	Min. pulse on time	20 mSEC		Number	one instantaneous and one	
	Min. pulse off time	30 mSEC			delayed	
COUNT INPUT	DC			Туре	DPD1, Form C	
CHARACTERIS- TICS	Max. count rate	2000/MIN (symmetrical input)		Operate Time	13 ms, max.	
	Min. Pulse on time	15 mSEC		Release Time	10 ms, max.	
	Min. Pulse off time	15 mSEC				
	Bounce Immunity (max. bounce open time)	5 mSEC			7A at 120, 240 or 24 VAC, 1/6	
	Pulse Contact Requirement	10 mA at line voltage		Ratings	HP. 3A at 24 VDC, 1.5A at 48 VDC, 0.5A at 125 VDC.	
	Single Cycle	interval or delayed		LIFE	100 million operations (no load)	
CONTROL MODES	Repeat Cycle	pulse (occurrence and duration 50 mSEC clocked)		120V	95 to 132V, 50/60 Hz inrush–0.3A running–0.06A at 120 VAC	
DISPLAY	Cycle Progress	3-digit display, 0.3 inch, high-intensity, blue programmable modes: DOWN & STOP, DOWN & GO, UP & STOP or UP & GO.	POWER REQUIREMENTS	240V	190 to 264V, 50/60 Hz inrush–0.15A running–0.03A at 240 VAC	
				24 VAC	19.2 - 26.4 VAC, 50 or 60 Hz Inrush–1 A Running–0.25 A at 24 VAC	
				24 VDC	19.2 - 26.4 VDC, 5% ripple Running120 A at 24 VDC	
	Count-Out at count-out		TEMPERATURE	32 to 140°F (0 to 60°C)		
	Counting Bar clo	when count switch is closed, when pulse is		Standard	hardware is provided for front-of-panel mounting.	
HOUSING	72mm <sup>2</sup> DIN size; plug-in design; fully gasketed, dust and water-tight in panel mounted installa- tions. NEMA 4 when mounted per installation instructions.		MOUNTING ACCESSORIES	Optional	Surface-mounting brackets with front-facing terminals	
				NEMA 12 molded case (1 counter)		
				NEMA 1 steel case (2 counters)		
	16 screw terminals accessible at rear: integral		WEIGHT	NET: AC - 1 lb., 6oz. DC - 10 oz.		
IERMINALS	wiring diagram.			SHIPPING: AC - 2 lbs., DC - 1 lb., 4 oz.		

**ISE, Inc** 10100 Royalton Rd. Cleveland, OH 44133 Tel: (440) 237-3200 Fax: (440) 237-1744 http://iseinc.com